



**Connect the rod with two screws and washers to the cross.  
Ensure that they are very tight.**

**The pics on the right show the screws to be tightened. Please ensure that the rod does not protrude too much off of the end of the cross. Take note of the directions to mount the rod in as illustrated above.**



**Place the cross on the ground and place the woven leg on the cross. It will not be held together by any protruding screws.**

**This is the view from the top after you have placed the woven leg. Note that the rod is straight up.**



**Take the base plate and position the rod through the centre. Make sure that the guide screws are **INSIDE** the woven leg. You may need two people for this: one to hold the base and the other to guide the 2 directional screws into the woven leg.**



**Once the base is in place, tighten the screw. You can use a tool like the one on the right as it will be easier to tighten the nuts.**

